

INSTALLATION & USER MANUAL

**DYNAMIC LOAD MANAGEMENT
-PREMIUM-**



CIRCONTROL
Mobility & eMobility

This document is copyrighted, 2016 by Circontrol, S.A. All rights are reserved. Circontrol, S.A. reserves the right to make improvements to the products described in this manual at any time without notice.

No part of this manual may be reproduced, copied, translated or transmitted in any form or by any means without the prior written permission of the original manufacturer. Information provided in this manual is intended to be accurate and reliable. However, the original manufacturer assumes no responsibility for its use, or for any infringements upon the rights of third parties that may result from its use.

All other product names or trademarks are properties of their respective owners.

V1.5, November edition 2016

CONTENTS

1	PREFACE	4
2	INSTALLATION GUIDELINES	5
2.1	IMPORTANT SAFETY INSTRUCTIONS.....	5
2.2	ELECTRICAL WIRING CONSIDERATIONS.....	6
2.2.1	Charge points – Input power supply.....	6
2.2.2	Power supply Line dimensioning.....	6
2.2.3	Charge point – Maximum output current.....	6
3	SYSTEM DESCRIPTION	7
3.1	PLUG WORK MODE	7
3.2	GENERAL BEHAVIOR.....	8
4	REQUISITES.....	11
4.1	ETHERNET COMMUNICATION.....	11
4.1.1	IP ADDRESSING	11
4.2	CHARGE POINTS.....	12
4.2.1	CONSIDERATIONS.....	12
4.3	LOAD MANAGEMENT PC	12
4.3.1	REQUIREMENTS.....	12
4.3.2	LICENSE KEY.....	12
4.4	POWER ANALYSER	13
4.4.1	MC3 CONSIDERATIONS.....	14
4.4.2	MC3 LOCATION.....	14
4.4.3	CVM-MINI CONNECTION.....	15
4.4.4	MC3 LOAD DIRECTION	15
4.4.5	RS-485 CONNECTION	16
4.4.6	RS-485 SETTINGS	17
4.5	TCP2RS	19
4.6	DISTRIBUTION BOARDS	19
5	LOAD MANAGEMENT SYSTEM	20
5.1	DISTRIBUTION BOARDS	20
5.2	LOAD MANAGEMENT TOOL	21
5.2.1	GENERAL	22
5.2.2	CHARGE POINTS.....	24
5.2.3	OFFLINE MODE.....	26
6	CHARGE POINTS – OFFLINE MODE	27

7	SCREENS	28
7.1	MAIN.....	28
7.1.1	TOP MENU.....	28
7.1.2	LOAD MANAGEMENT.....	29
7.1.3	POWER MONITORING.....	29
7.1.4	CHARGE POINTS.....	29
7.1.5	PLUG STATUS.....	30
7.2	CHARGE POINTS.....	30
7.2.1	STATUS OF THE CHARGE POINTS	31
7.3	POWER MONITORING.....	34
7.3.1	DISTRIBUTION PANEL	34
7.3.2	CONSUMPTION PER PHASE.....	34
7.4	LOAD MANAGEMENT	35
7.4.1	PRIORITY SCHEDULE.....	36
7.4.2	TABLE PER PHASES	36
7.4.3	ANALYSER	38
7.4.4	PARAMETERS.....	39
7.5	POWER GRAPHS	41
8	FAQ	42
8.1	HOW TO INSTALL & CONFIGURE?	42
8.1.1	Installation	42
8.1.2	Configuration	45
8.1.3	Electric configuration	48
8.1.4	Check.....	48
8.2	HOW TO CHANGE THE MAXIMUM OUTPUT CURRENT?	49
8.3	HOW TO IMPORT REPORTS?	51
8.3.1	Charge Transactions view.....	51
8.3.2	Charge Points view.....	52
8.4	HOW TO KNOW WHICH IP ADDRESSES DO WE HAVE ASSIGNED?	53
8.5	HOW TO APPLY THE IP ADDRESS?	54
9	ANNEX I: RELEASE NOTES	55
9.1	DOCUMENT VERSION 1.4 / DLM VERSION 2.1	55
9.2	DOCUMENT VERSION 1.5 / DLM VERSION 2.2.....	55

1 PREFACE

This document provides information about the Dynamic Load Management - Premium. It is a system that balances the supply of electricity given to the electric vehicles depending on the building demand.

THE FOLLOWING SYMBOLS ARE USED FOR IMPORTANT SAFETY INFORMATION IN THIS DOCUMENT



ELECTRIC RISK!

Take precautions to make the electrical connection inside the units.

Units must be disconnected from any power source during commissioning.



ATTENTION!

Indicates that the damage to property can occur if appropriate precautions are not taken.



TAKE NOTE!

Indicates some kind of tip or advise.

2 INSTALLATION GUIDELINES

2.1 IMPORTANT SAFETY INSTRUCTIONS



Read carefully all the instructions before starting to ensure properly installation and configuration.

The units must be installed safely and ensure adequate protection.

- Comply strictly with electrical safety regulations according to your country.
- Do not make repairs or manipulations with the units energised.
- Only trained and qualified personnel should have access to low-voltage electrical parts inside the devices.
- Check the installation annually by qualified technician.
- Dynamic Load Management is compatible neither with charging Mode 1 nor with Mode 4.
- Main supply can be either three-phase or single-phase.
- Charge points must be single-phase.
- Do not use Dynamic Load Management for another purpose which has been conceived and only with CIRCONTROL Charge points. Otherwise, CIRCONTROL will reject all responsibility and the warranty will be void.
- Remove from service any item that has a fault that could be dangerous for users (broken plugs, caps that don't close...).
- Use only CIRCONTROL supplied spare parts.

2.2 ELECTRICAL WIRING CONSIDERATIONS



Before start with the wiring connection of the Charge points shall take in consideration this section.

2.2.1 Charge points – Input power supply

If the Charge points do not include elements of electrical protection, consider the following instructions:

The input power supply line must be hardwired from a distribution board to the charge point under electrical safety regulations according to your country regulations. Minimum safety required protections:

- RCD: Type A. $I_{\Delta N}=0.03A$.
- MCB: maximum value according to the maximum output current of the Charge points.

2.2.2 Power supply Line dimensioning

The dimensioning of the input power supply line must be checked by a qualified electrician.

The power supply must have a general switch and a unique differential, installed according to the standards of local or state security.

Check that the power supply line has enough capacity to power the unit; length, cable section, and the protection thereof (hose or cover) should be adequate for the unit.

Check using a multimeter that the supply voltage is stable within acceptable values.

2.2.3 Charge point – Maximum output current

If the power supply is lower than the maximum output current of the Charge points, an adjustment to a lower nominal current must be performed using the tool “Charge Point Setup”. Do not modify this value if the power supply is not restrictive.

Note that depending on the model of Charge point the maximum output current may vary.

Please refer to “FAQ” section in order to know how to change this value.

3 SYSTEM DESCRIPTION

Load Management System monitors the power consumption of the building in real-time and all contracted power that is not being used is provided to the electric vehicles.

All the dedicated current for electric vehicle is equally distributed on each plug in order to not exceed the contracted power.

It is recommended to have at least 6A (Mode 3 minimum current permitted) per socket in the worst case when the consumption of the building is too high.

Load Management system can pause charging transactions when the current for each socket is less than 6A and resuming charging transactions when the current goes back to 6A or greater for each socket.



If the available power for the electric vehicles is very low, the longer it takes to the vehicle to charge up to 100%

3.1 PLUG WORK MODE

There are two groups of plug work mode:

- a) Priority plugs
- b) Standard plugs (no priority)

Priority plugs preferably charge before than standards. System gives the maximum current to the priority plugs allowing charging faster than standard plugs and the remaining current not used by priority vehicles is provided to the standard plugs (if available and according between the contracted power and the building consumption).

EXAMPLE

Available current for EV: 40A

1 priority plug charging at: 32A

Remaining current for standard plugs: $40 - 32 = 8A$

- Priority plugs only become in operation within an established time slot.
- Priority plugs are an optional feature. By default is disabled and can be enabled any time.

The standard plugs start a charging transaction in the following cases:

- Remaining current not being used by priority vehicles. Explained in example above.
- No priority plugs are charging.
- Present time slot is not set as priority and all plugs are considered as standard.

3.2 GENERAL BEHAVIOR

In both groups (priority and/or standard plugs) the load management policy works as follows:

1. Available current is equally distributed on each occupied plug.
2. System pause one by one the existing charging transactions if the available current is not enough to keep charging all the plugs simultaneously.
3. Plugs remain paused until enough power is available back again. Display of the charge point shows:



4. System resumes all the paused charging transactions one by one as a queue and regulating the current on each plug without exceeding the contracted power.
5. System also resumes one paused charging transaction after one vehicle has the battery fully charged.
6. System pauses a charging transaction if the EV switches to State B after a short period of time, in addition it is queued and the current now is distributed to the other active charging transactions. *This is an optional parameter and can be changed if necessary.

7. Each plug has one ID internally assigned. This IDs cannot be changed:

CHARGE POINT	PLUG	ID
01	A	1
	B	2
02	A	3
	B	4
03	A	5
	B	6
04	A	7
	B	8
05	A	9
	B	10
06	A	11
	B	12
07	A	13
	B	14
08	A	15
	B	16
09	A	17
	B	18
10	A	19
	B	20
11	A	21
	B	22
12	A	23
	B	24
13	A	25
	B	26
14	A	27
	B	28
15	A	29
	B	30

These IDs are only needed in following cases:

- A. Insufficient power to keep charging all plugs simultaneously at 6A.
- B. Enough power available to resume existing paused charging transactions.

Case A

Existing started charging transactions are become paused until not exceed the maximum contracted power from the highest plug ID to the smallest plug ID.

EXAMPLE

Charging ID plugs: 1,2,3,4

Plug ID queue: 4 → 3 → 2

- Not enough power to have 4 plugs charging simultaneously. Plug ID=4 is the first one to pause.
- Not enough power to have 3 plugs charging simultaneously. Building + EV real-time consumptions are exceeding the contracted power. ID=3 is the following to pause.
- Exceeding contracted power. ID=2 is paused.
- ID=1 remains charging. Building + EV real-time consumptions are less than contracted power.

Case B

Existing paused charging transactions are resumed from the smallest plug ID to the highest plug ID.

EXAMPLE

Following above Case A example, charging ID plugs: 1


Plug ID queue: 2 → 3 → 4

- Building + EV real-time consumptions are less than contracted power. Plug ID=2 is the first one to resume.
- 2 plugs are now charging simultaneously. Building + EV real-time consumptions are less the contracted power. ID=3 is the following to resume.
- 3 plugs are now charging simultaneously. Resuming plug ID=4.
- 4 plugs now charging simultaneously. Building + EV consumptions don't exceed the contracted power.

4 REQUISITES

4.1 ETHERNET COMMUNICATION

Charge points, building power analyser and the load management PC are together connected into a network switch (not provided):



Please consider the distance between each device (charge point, Building Meter or PC) and network switch. Maximum allowed length of the Ethernet cable is 100 meters.



It is highly recommended using at least FTP Ethernet cable. Cat 5e.

4.1.1 IP ADDRESSING

Load Management system only works under static IP addresses and each device connected to the network switch needs a static IP address:

- Charge points
- TCP2RS
- Load Management PC



Please refer to the section “FAQ” to consult how to assign IP addresses.

4.2 CHARGE POINTS

Load management system is compatible with following models:

- Dual outlet AC charge point model.
- Single outlet AC charge point model.

4.2.1 CONSIDERATIONS

- Dual and single AC charge points models must have Mode 3 charge mode (Type 1, Type 2 or Type 3 connectors).
- Mode 1 and Mode 2 charging modes are not compatible (CEE 7/4 sockets) under load management system.
- DC chargers are not compatible.

4.3 LOAD MANAGEMENT PC

4.3.1 REQUIREMENTS

Minimum requirements

- **CPU:** Dual Core
- **RAM:** 2Gb RAM
- **S.O.:** Windows XP or higher

4.3.2 LICENSE KEY

Hasp USB key must be plugged in and the LED ON in the server:




If the LED from the hasp is not lighting ON, Load Management system will be automatically OFF in the following one hour.

4.4 POWER ANALYSER

Power analyser is an optional feature when the power line is not fully dedicated for electric vehicle because other electric devices are connected on the same supply.

The analyser allows to the Load Management System to prevent excess power consumption by electric vehicle considering the real-time consumption from the building.

Following devices are needed to read the power consumption of the building for the load management system:




- **TCP2RS+:** RS485 (Modbus RTU) to Ethernet (Modbus TCP) converter.
- **CVM-MINI:** Three-phase power analyser.
- **MC3:** Current transformer, needed to measure the consumption.



Only CVM-MINI power analyser is compatible with the Load Management System.

4.4.1 MC3 CONSIDERATIONS


MC3 is the current transformer used with CVM-MINI. Different MC3 can be found for each wiring need:




Wiring section of the building supply must be checked by a qualified electrician in order to select the correct MC3.

4.4.2 MC3 LOCATION

Building power supply line and Electric Vehicle supply line must be separated from the main distribution board.



4.4.3 CVM-MINI CONNECTION



CVM-MINI	MC3 Connection
PIN 01	1S1
PIN 02	COM
PIN 03	2S1
PIN 04	Nothing
PIN 05	3S1
PIN 06 – 09	Nothing

CVM-MINI	Voltage connection
PIN 10	L1
PIN 11	L2
PIN 12	L3
PIN 13	N


CVM-MINI	Supply	
PIN 14	L	230V _{AC}
PIN 15	N	



Only trained and qualified personnel should manipulate the wiring.

4.4.4 MC3 LOAD DIRECTION


Before installing the current transformer, pay attention to the load direction from power supply and the correct order of the phases in order to ensure the correct reading of the power consumption.



Improper installation of the current reader can cause a malfunction of the load management system.

4.4.5 RS-485 CONNECTION

TCP2RS and CVM-MINI must be connected between each other using a 2 wire twisted shielded communication cable (STP CAT.5e recommended).





Respect the polarity of the wiring connections otherwise load management system cannot communicate with CVM-MINI.








4.4.6 RS-485 SETTINGS

Load management system expects to find the CVM-MINI under following RS485 connection details:

- **Peripheral number:** 1
- **Baud rate:** 19200

Use the display and buttons of the device in order to establish the above configuration:


STEP	ACTION
1	<p>Make sure to having powered the CVM-MINI in order to apply the new settings to the device.</p> <p>Voltage measurement from each phase is the default information displayed by the screen. Following picture shows an example:</p> 
2	<p>To setup communications, first press <i>Reset</i> key for a second and immediately press <i>Setup</i> key for a long time until following message is displayed on screen:</p> 

3	<p>Press  button two times until following message is displayed on screen:</p> <div data-bbox="722 309 987 472" data-label="Image"> </div> <p>This option allows to modifying the peripheral number of the energy meter.</p>
4	<p>To change the peripheral number, repeatedly press the  key to increasing the value of the digit which is flashing at the time.</p> <p>When the required value is on the screen, move on the following digit by pressing  to change the remaining values.</p> <p>Press  key to confirm the value entered.</p>
5	<p>Next option on the setup menu is baud rate. Press  until 19200Bps value is displayed as shown:</p> <div data-bbox="715 1014 994 1189" data-label="Image"> </div> <p>Press  key to confirm the value entered.</p>
6	<p>Press 4 times  key to return to the main screen:</p> <div data-bbox="722 1388 986 1552" data-label="Image"> </div>
7	<p><u>Process completed.</u></p> <p>No additional configuration is required to operate with CVM-MINI energy meters.</p>

4.5 TCP2RS

TCP2RS is a gateway between RS-485 devices and Load Management System.

Before installing the device, please take note about the MAC code labelled in one side of the device. An IP address must be applied once the device is connected to the network.



4.6 DISTRIBUTION BOARDS

Load management is ready to work only under 1 distribution board (three-phase connection) and a maximum of 15 charge points (30 sockets max.).

All the charge points must be connected in single-phase and distributed between L1, L2 or L3.


5 LOAD MANAGEMENT SYSTEM

All charge points are deactivated first time Load Management System is started and manual setting must be done in order to enable each one.

5.1 DISTRIBUTION BOARDS


There is no specific electric order about how the software expects to have installed all the charge points, but it is required to set the electric connection of each Charge point the first time Load Management System is started.

Example of distribution:



Only trained and qualified personnel should manipulate the wiring.


Use *Load Management tool* software to define electric phase connection of the socket otherwise the system cannot operate with the charge point:




Load
Management
Tool.exe

5.2 LOAD MANAGEMENT TOOL

By executing the application this window will appear:



The IP address of the Load Management System needs to be introduced, in order to retrieve its data and check the configuration.



5.2.1 GENERAL

The screenshot shows a configuration window with three tabs: "General", "Charge Points", and "Offline Mode". The "General" tab is selected. It contains three main sections:

- Power Supply:** Includes a text input for "MCCB (A):", a text input for "Contracted Power (kW):", and a dropdown menu for "Min. Charge current (A):" with a value of 8.
- Building Analyzer:** Includes a "Status:" dropdown menu set to "Enabled", a text input for "Safety current (A):", and a dropdown menu for "Working range (%):" with a value of 10.
- State of the vehicle:** Includes a "State B detection:" dropdown menu set to "Enabled", a dropdown menu for "Waiting time (s):" with a value of 600, a dropdown menu for "Retries:" with a value of 3, a dropdown menu for "Retry period (s):" with a value of 1800, and a dropdown menu for "Detect low consumption:" set to "Disabled".

At the bottom right of the window are "Save" and "Cancel" buttons.

Power Supply

This is a close-up of the "Power Supply" section from the configuration window. It contains three fields:

- MCCB (A):** A text input field.
- Contracted Power (kW):** A text input field.
- Min. Charge current (A):** A dropdown menu currently showing the value 8.

- Max MCCB current
- Contracted Power (only available for Dynamic Load Management Premium)
- Current that the Load Management System understands as the minimum charging current per socket (8 Amps by default).



It is highly recommended to apply a 15% margin when choosing the caliber of the MCCB, in order to prevent it from working at the limit.

Building Analyser

Only available for Dynamic Load Management Premium.

Building Analyser

Status:

Safety current (A):

Working range (%):

- Status (Enabled/Disabled)
- Safety current
- Working range

State of the Vehicle

State of the vehicle

State B detection:

Waiting time (s):

Retries:

Retry period (s):

Detect low consumption:

- State B detection status
- Waiting time
- Number of retries
- Period between retries
- Low consumption status

5.2.2 CHARGE POINTS

General
Charge Points
Offline Mode

	Name	IP	Plugs	A - Phase	B - Phase	A - Priority	B - Priority
<input checked="" type="checkbox"/>	CP01	192.168.110.33	2	L1	L1	No	No
<input checked="" type="checkbox"/>	CP02	192.168.110.31	1	L1	-	No	-
<input checked="" type="checkbox"/>	CP03	192.168.110.35	2	L1	L1	No	No
<input checked="" type="checkbox"/>	CP04	192.168.110.36	2	L1	L1	No	No
<input checked="" type="checkbox"/>	CP05	192.168.110.37	2	L1	L1	No	No
<input checked="" type="checkbox"/>	CP06	192.168.110.29	2	L2	L2	No	No
<input checked="" type="checkbox"/>	CP07	192.168.110.34	2	L2	L2	No	No
<input checked="" type="checkbox"/>	CP08	192.168.110.39	2	L2	L2	No	No
<input checked="" type="checkbox"/>	CP09	192.168.110.25	2	L2	L2	No	No
<input type="checkbox"/>	CP10	192.168.110.24	-	-	-	-	-
<input checked="" type="checkbox"/>	CP11	192.168.110.21	2	L3	L3	No	No
<input checked="" type="checkbox"/>	CP12	192.168.110.23	1	L3	-	No	-
<input checked="" type="checkbox"/>	CP13	192.168.110.20	1	L3	-	No	-
<input checked="" type="checkbox"/>	CP14	192.168.110.26	2	L3	L3	No	No
<input checked="" type="checkbox"/>	CP15	192.168.110.30	1	L3	-	No	-

Configuration
Charge Point: CP01
IP Address: 192 . 168 . 110 . 33
Plugs: 2
Phase: A: L1 B: L1
Priority: ☐ ☐
Apply

Save
Cancel

Table

Identifier
Enable/Disable
Address
Number of plugs
Phase of each plug
Priority of each plug

	Name	IP	Plugs	A - Phase	B - Phase	A - Priority	B - Priority
<input checked="" type="checkbox"/>	CP01	192.168.110.33	2	L1	L1	No	No
<input checked="" type="checkbox"/>	CP02	192.168.110.31	1	L1	-	No	-
<input checked="" type="checkbox"/>	CP03	192.168.110.35	2	L1	L1	No	No
<input checked="" type="checkbox"/>	CP04	192.168.110.36	2	L1	L1	No	No
<input checked="" type="checkbox"/>	CP05	192.168.110.37	2	L1	L1	No	No
<input checked="" type="checkbox"/>	CP06	192.168.110.29	2	L2	L2	No	No
<input checked="" type="checkbox"/>	CP07	192.168.110.34	2	L2	L2	No	No
<input checked="" type="checkbox"/>	CP08	192.168.110.39	2	L2	L2	No	No
<input checked="" type="checkbox"/>	CP09	192.168.110.25	2	L2	L2	No	No
<input type="checkbox"/>	CP10	192.168.110.24	-	-	-	-	-
<input checked="" type="checkbox"/>	CP11	192.168.110.21	2	L3	L3	No	No
<input checked="" type="checkbox"/>	CP12	192.168.110.23	1	L3	-	No	-
<input checked="" type="checkbox"/>	CP13	192.168.110.20	1	L3	-	No	-
<input checked="" type="checkbox"/>	CP14	192.168.110.26	2	L3	L3	No	No
<input checked="" type="checkbox"/>	CP15	192.168.110.30	1	L3	-	No	-

Configuration

Configuration

Charge Point: CP01

IP Address: 192 . 168 . 110 . 33

Plugs: 2

Plugs

	A	B
Phase:	L1	L1
Priority:	<input type="checkbox"/>	<input type="checkbox"/>

Apply

- IP address of the Charge point.
- Number of plugs (1 or 2)
- Phase of each plug (L1, L2 or L3)
- Priority of each plug (Priority or No-Priority)

*By clicking “Apply”, the configuration is set in the table. Nevertheless, the changes don’t apply in the Load Management System until the “Save” button is clicked:

General Charge Points Offline Mode

	Name	IP	Plugs	A - Phase	B - Phase	A - Priority	B - Priority
<input checked="" type="checkbox"/>	CP01	192.168.110.33	2	L1	L1	No	No
<input checked="" type="checkbox"/>	CP02	192.168.110.31	1	L1	-	No	-
<input checked="" type="checkbox"/>	CP03	192.168.110.35	2	L1	L1	No	No
<input checked="" type="checkbox"/>	CP04	192.168.110.36	2	L1	L1	No	No
<input checked="" type="checkbox"/>	CP05	192.168.110.37	2	L1	L1	No	No
<input checked="" type="checkbox"/>	CP06	192.168.110.29	2	L2	L2	No	No
<input checked="" type="checkbox"/>	CP07	192.168.110.34	2	L2	L2	No	No
<input checked="" type="checkbox"/>	CP08	192.168.110.39	2	L2	L2	No	No
<input checked="" type="checkbox"/>	CP09	192.168.110.25	2	L2	L2	No	No
<input type="checkbox"/>	CP10	192.168.110.24	-	-	-	-	-
<input checked="" type="checkbox"/>	CP11	192.168.110.21	2	L3	L3	No	No
<input checked="" type="checkbox"/>	CP12	192.168.110.23	1	L3	-	No	-
<input checked="" type="checkbox"/>	CP13	192.168.110.20	1	L3	-	No	-
<input checked="" type="checkbox"/>	CP14	192.168.110.26	2	L3	L3	No	No
<input checked="" type="checkbox"/>	CP15	192.168.110.30	1	L3	-	No	-

Configuration

Charge Point: CP01

IP Address: 192 . 168 . 110 . 33

Plugs: 2

Plugs

	A	B
Phase:	L1	L1
Priority:	<input type="checkbox"/>	<input type="checkbox"/>

Apply

Save Cancel

5.2.3 OFFLINE MODE

*By clicking “Apply”, the configuration is set in the table. Nevertheless, the changes don’t apply in the Load Management System until the “Save” button is clicked:

The screenshot shows a software interface with three tabs: 'General', 'Charge Points', and 'Offline Mode'. The 'Offline Mode' tab is active, displaying a table of charge points and a configuration panel on the right.

Name	Model	IP	Status	Interval	Work Mode	Offline Current
CP01	WB2MC-SMART	192.168.110.33	Enabled	120	3	8
CP02	DEMO PLUGS	192.168.110.31	Disabled	-	-	-
CP03	WB2SIM	192.168.110.35	Enabled	120	3	8
CP04	WB2SIM	192.168.110.36	Enabled	120	3	8
CP05	WB2SIM	192.168.110.37	Enabled	120	3	8
CP06	WB2MC-DEMO	192.168.110.29	Disabled	-	-	-
CP07	WB2SIM	192.168.110.34	Enabled	120	3	8
CP08	WB2SIM	192.168.110.39	Enabled	120	3	8
CP09	WB2MC-DEMO	192.168.110.25	Disabled	-	-	-
CP12	WB2MC-DEMO	192.168.110.23	Enabled	120	3	8
CP13	WB2MC-DEMO	192.168.110.20	Enabled	120	3	8
CP14	WB2MC-DEMO	192.168.110.26	Disabled	-	-	-

Offline configuration

Charge Point: CP01

Model: WB2MC-SMART

Heartbeat interval (s): 120

Work Mode: 3

Current (A): 8

Apply

Save

Cancel

- Heartbeat interval
- Offline mode (0, 1, 2 or 3)
- Offline current



For further information about the Offline Mode, please refer to section “CHARGE POINTS – OFFLINE MODE”

6 CHARGE POINTS – OFFLINE MODE

Sometimes, the network connection can be lost due to an unexpected issue such as the PC is powered OFF or even the server is shutdown. In those cases, the Charge points cannot see the Master and they are the ones who make the decisions in order to keep supplying the electric vehicles, their behaviour can be configured in four different ways:

MODE	ACTIVE CHARGING TRANSACTIONS	NEW CHARGING TRANSACTIONS	COMMENTS
0	Paused.	Paused.	-
1	Still active, without modifying the current.	Paused.	-
2	Still active, the maximum current is set to 8A* per socket.	Paused.	*The maximum current can be modified.
3	Still active, the maximum current is set to 8A* per socket.	Start charging at 8A* per socket.	

When the connection is re-established and the Charge points are able to see the Master, they are again under Master commands.


7 SCREENS

7.1 MAIN


Status information about Charge points and Load Management.




7.1.1 TOP MENU




7.1.2 LOAD MANAGEMENT




7.1.3 POWER MONITORING



7.1.4 CHARGE POINTS




7.1.5 PLUG STATUS



7.2 CHARGE POINTS

Information about the Charge points and the Plugs.



7.2.1 STATUS OF THE CHARGE POINTS

EV status indicator ¹		License plate	Plug status ²		Plug identifier	Charging Point identifier	Modify the license plate ³
A	AVAILABLE	01	AE-1111-FF				
	AVAILABLE						
B	AVAILABLE	02	RR-0000-FE				
	AVAILABLE						
A	AVAILABLE	03	DD-3458-GG				
	AVAILABLE						
B	AVAILABLE	04	DS-2215-RR				
	AVAILABLE						
A	CHARGING	05					
	CHARGING						
B	CHARGING	06					
	CHARGING						
A	CHARGING	07	3358-DSZ				
	CHARGING						
B	CHARGING	08					
	CHARGING						
A	CHARGING	09					
	CHARGING						
B	CHARGING	10					
	CHARGING						
A	CHARGING	11					
	CHARGING						
B	CHARGING	12					
	CHARGING						
A	CHARGING	13					
	CHARGING						
B	CHARGING	14					
	CHARGING						
A	CHARGING	15					
	CHARGING						
B	CHARGING	16					
	CHARGING						


¹ (a) EV indicator based on the priority and if a car is plugged in or not.


² (b) Different plug status.

³ (c) A licence plate or identifier can be assigned to a particular plug.

(a) EV status indicators:

 Non-priority / Not plugged in


 Non-priority / Plugged in

 Priority / Not plugged in


 Priority / Plugged in

(b) Plug status:

STATUS	DEFINITION
AVAILABLE	The plug is available and ready.
CHARGING	The vehicle in this plug is charging.
PAUSED	The charging transaction is paused.
OFFLINE	Network connection failure between the Load Management System and the Charge point
FAULTED	The charge point has some kind of error, please contact technical assistance.
ERR. CFG	The parameters of the charge point configuration have to be modified. This will only happen while the commissioning is taking place.
DISABLED	The Charge point is disabled.


- (c) To assign a license plate to a certain Plug, click on .

The next dialog will appear:



The dialog box is titled "Force variables" and has a close button in the top right corner. It contains a section labeled "EV_PLATES" with a sub-label "CP01_A". Below this, there is a text input field containing the value "AE-1111-FF". At the bottom of the dialog, there are two buttons: "Ok" with a green checkmark icon and "Cancel" with a red X icon.


If no license plate is needed a '-' symbol must be placed, the field cannot be void. As shown below:




This dialog box is identical to the one above, but the text input field under "CP01_A" contains a single hyphen "-" instead of a license plate number. The "Ok" and "Cancel" buttons are at the bottom.

7.3 POWER MONITORING

- Status of the Charge points
- Distribution panel of different power consumption
- Current consumption table per phase



7.3.1 DISTRIBUTION PANEL




7.3.2 CONSUMPTION PER PHASE

CONSUMPTION CHART	L1	L2	L3	
MCCB MAX. CURRENT (A)	100	100	100	MCCB Max Current
TOTAL CONSUMPTION (A)	98,4	97,6	99	Total consumption
BUILDING CONSUMPTION (A)	20,2	20,6	20,6	Building consumption
EV CONSUMPTION (A)	78,4	77,6	78	Total EV consumption

7.4 LOAD MANAGEMENT

- Status of the Charge points
- Enable/Disable priority schedule
- Set priority time slots
- Table per phases
- Analyser
- Parameters



Powered by CirCarLife Scada

7.4.1 PRIORITY SCHEDULE

PRIORITY SCHEDULE

☒ ON
 ☐ OFF

00h - 01h

-

01h - 02h

-

02h - 03h

-

03h - 04h

-

04h - 05h

-

05h - 06h

-

06h - 07h

-

07h - 08h

✓

08h - 09h

-

09h - 10h

✓

10h - 11h

✓

11h - 12h

✓

12h - 13h

✓

13h - 14h

-

14h - 15h

-

15h - 16h

-

16h - 17h

-

17h - 18h

-

18h - 19h

-

19h - 20h

-

20h - 21h

-

21h - 22h

-

22h - 23h

-

23h - 00h

-

Enable / Disable priority

Mark / Unmark priority time slots

7.4.2 TABLE PER PHASES

When priority schedule is ON, the table shows differentially Priority and Non-priority:

	EV GROUPS	PRIORITY			NORMAL			ALL		
		L1	L2	L3	L1	L2	L3	L1	L2	L3
Load Management state ¹	STATE	1	1	1	3	3	3	-	-	-
Number of plugs able to charge	MAX. ALLOWED PLUGS	2	2	2	2	1	1	-	-	-
Plugs charging	CHARGING	2	2	2	2	1	1	-	-	-
Plugs paused	PAUSED	0	0	0	2	2	1	-	-	-
Total installed plugs	TOTAL PLUGS	3	3	3	6	6	6	-	-	-
Current available	AVAILABLE CURRENT (A)	80	79	79	16	15	15	-	-	-
Current shared	SHARED CURRENT (A)	40	39,5	39,5	8	15	15	-	-	-
Next plug to resume	NEXT ALLOWED PLUG	0	0	0	17	15	16	-	-	-
Next plug to pause	NEXT PAUSED PLUG	8	9	10	14	12	13	-	-	-

When priority schedule is OFF, the table shows all data in one column:


	EV GROUPS	PRIORITY			NORMAL			ALL		
		L1	L2	L3	L1	L2	L3	L1	L2	L3
Load Management state ¹	STATE	-	-	-	-	-	-	1	1	1
Number of plugs able to charge	MAX. ALLOWED PLUGS	-	-	-	-	-	-	6	5	4
Plugs charging	CHARGING	-	-	-	-	-	-	4	3	3
Plugs paused	PAUSED	-	-	-	-	-	-	2	2	1
Total installed plugs	TOTAL PLUGS	-	-	-	-	-	-	9	9	9
Current available	AVAILABLE CURRENT (A)	-	-	-	-	-	-	80	79	79
Current shared	SHARED CURRENT (A)	-	-	-	-	-	-	13,3	15,8	19,8
Next plug to resume	NEXT ALLOWED PLUG	-	-	-	-	-	-	17	15	16
Next plug to pause	NEXT PAUSED PLUG	-	-	-	-	-	-	14	12	13

¹ There are five Load Management states, these states are dynamic and change based on the active Charging Transactions and the available power:

STATE	DESCRIPTION	COMMENTS
1	Available power	All active Charging Transactions can charge simultaneously at least at the minimum current (8A by default).
2	Power decreasing	New Charging Transactions start progressively without exceeding the contracted power.
3	Limited power	New Charging Transactions are paused until there is enough power back again.
4	Power exceeded	Not all active Charging Transactions can charge simultaneously and one or more need to be paused in order to avoid an overload.
5	Unavailable power	Not enough power available and all Charging Transactions are paused.

7.4.3 ANALYSER

BUILDING METER	L1	L2	L3	
STATUS	ON			State of the analyzer
OFFLINE CURRENT (A)	25			Default current when the analyzer is offline
REALTIME CURRENT (A)	2	2	2	Instantaneous current
AVERAGE CURRENT (A)	2	2	2	Average current
MAX.CURRENT ALARM (A)	3	3	3	Most restrictive current
MAX.CURRENT PREALARM (A)	3	3	3	Max safety current
MIN. CURRENT PREALARM (A)	1	1	1	Min safety current
MIN. CURRENT ALARM (A)	1	1	1	Less restrictive current
CURRENT THRESHOLD (%)	10			Safety margin



- Instantaneous current: current that is being used in real time.
- Average current: calculated mean of the actual current and is used to adjust the “Safety margin”.
- Safety margin: customizable parameter used to protect the installation from overloads or unexpected current peaks.

7.4.4 PARAMETERS

SETTINGS			
MCCB MAX CURRENT (A)		50	MCCB Max current
CONTRACTED POWER (kW)		36	Contracted power
VEHICLE STATE B	DETECTION STATUS	ON	State B detection status
	MAX. WAITING TIME (s)	60	Max waiting time
	NUMBER OF RETRIES	2	Number of retries
	BETWEEN RETRIES (s)	30	Period between retries
LOW CONSUMPTION		ON	Low consumption status
MIN. CHARGING CURRENT (A)		8	Minimum charging current

State B detection:

This is a customizable feature, meaning that can be enabled/disabled and its parameters can be adjusted at will.

Switching it ON allows us to keep supplying the electric vehicles even if the EVs switch from state C to B.

When this happens, the Load Management System is monitoring during a time interval named “Max waiting time” (customizable parameter) to discriminate whether the vehicle is in state B because:

- It decides to rest and stops charging for a while or if someone opens the doors of the vehicle.
- It is fully charged.

If the EV remains in state B, the Charging Transaction is queued in order to give its assigned current to the other active Charging Transactions.

If the EV demands power while “Max waiting time” and there is enough power, the Charging Transaction is resumed. Nevertheless, if there is no power available the Charging Transaction is queued.

The Charging Transaction will be in queue for a certain period of time named “Period between retries” (customizable parameter). When this period ends, the cycle will start again and will be repeated as many times as the parameter “Number of retries” is set. Furthermore, when this limit is exceeded no more retries are made.

It may be turned OFF, if there is enough power to supply all the Charge points at least at the minimum current.

Low consumption status:

By switching it ON, the current from one EV will distribute to the others when its consumption is too low.

When an EV is charging below 6A (limit set by the IEC 61851-1 standard) the Charging Transaction will be queued.

This queue is the same as the mentioned in the previous section (State B detection) and the Charging Transaction follows the same procedure.

It may be turned OFF, if there is enough power to supply all the Charge points at least at the minimum current.


It is highly recommended to enable this two features when:



- a) The contracted current is not enough to supply all the Plugs at once.**
 - b) The Charge points and the building are sharing the same power supply.**
-

7.5 POWER GRAPHS

- Power consumption of the building, the EV and the sum of both in real time, compared to the contracted power.
- Historical graphs.



8 FAQ


8.1 How to install & configure?

8.1.1 Installation


1. Click on the icon to start the installation:




2. Choose the language:




3. Next.




4. Accept.




5. Add Company name.




6. Select a setup type.



7. Install.




8. Finish.




8.1.2 Configuration


1. Open “CirCarLife SCADA Engine Manager”.




2. Take note of the path where the program was installed.




3. Go to that folder and replace the “Cfg” folder with the one provided by CIRCONTROL.




4. Open “CirCarLife SCADA Engine Manager” and click Start.



5. Check that the indicator turned green.



6. Take note of the Port configured (by default 8080, if it is required to be changed click “Modify”).




8.1.3 Electric configuration

To set the electric configuration of each Charging Point, follow the instructions described on section “LOAD MANAGEMENT TOOL”.

8.1.4 Check

Open “CirCarLife SCADA Client Html5”.



Default Connection details: <http://127.0.0.1:8080>

In order to access remotely, check the IP address of the PC where the DLM is installed.




Port 8080 can be modified with the “CirCarLife SCADA Engine Manager”


8.2 How to change the maximum output current?

If the maximum output current of a Charge point needs to be modified in order to not exceed the value of the power supply follow these steps:

1. Execute the tool “Charge Point Setup”.



2. By executing the application this window will appear:



Charge Point Setup can be downloaded from CIRCONTROL
webpage: <http://circontrol.com/downloads/>

3. Enter the Charge point IP Address and click Connect.

Charge Point Setup (1.1c)

Communication

IP Address: 192 . 168 . 110 . 30 **Connect**

Charge Point Information

Charge Point Model:

Firmware installed:

[Go to setup.html](#) [Go to integrations.html](#)

Plug Information

Plugs	Max. Current	Status

NOTE: Only Mode3 plugs are listed

SELECTED DEVICES -> Max. Current per plug (A): 32

Apply settings

4. Modify the current and click Apply settings.

Charge Point Setup (1.1c)

Communication

IP Address: 192 . 168 . 110 . 30 **Connect**

Charge Point Information

Charge Point Model: WBM-SMART-TRI

Firmware installed: Platform version: 2.2b
Engine version: CirCarLife Scada 4.2.2

[Go to setup.html](#) [Go to integrations.html](#)

Plug Information

Plugs	Max. Current	Status
<input checked="" type="checkbox"/> Plug - Mode 3	16	OK

NOTE: Only Mode3 plugs are listed

SELECTED DEVICES -> Max. Current per plug (A): 16

Apply settings



Depending on the model of Charge point the maximum output current may vary.

8.3 How to import reports?

The Load Management System does not support importing reports of the Charging Transactions. In order to do that a Tool named EV Reports is needed.




8.3.1 Charge Transactions view

List of Charging Transactions during the desired interval.

[illegible]

8.3.2 Charge Points view

List of Charge points where information is extracted.



Note: Only one time is needed to add all the charge points. Every time EVR is started it will remember all the charge points listed last time.




EV Reports, as well as its manual, can be downloaded from

CIRCONTROL webpage: <http://circontrol.com/downloads/>

For further information please consult it.

8.4 How to know which IP addresses do we have assigned?

1. Open the client and get connection to the Load Management System.
2. Go to Device Status.
3. Select the desired charge point. In the right pane there are the connection details.




8.5 How to apply the IP address?

Take note about the MAC identifier of each Charge point and TCP2RS converter in order to apply IP address:


CHARGE POINT ID	MAC	IP
01	00:26:45:00:11:22	192.168.110.10
02	00:26:45:00:11:23	192.168.110.11
03	00:26:45:00:11:24	192.168.110.12

EXAMPLE

Use the IPSetup tool and the mac code from charge point (labelled in one side of the charge point) to apply IP addresses.



Example:



9 ANNEX I: RELEASE NOTES

9.1 Document Version 1.4 / DLM Version 2.1

- Optimized current reserve between Priority and Non-priority plugs.
- Charge Point firmware check

9.2 Document Version 1.5 / DLM Version 2.2

- Fuse protection added
- Optimized graphics visualization in case there is no communication with the Meter.



CIRCONTROL

Mobility & eMobility

www.circontrol.com